

**RX**only

## Quick Guide Cerebral State Monitor CSM-2





CSI trend histogram with 5-minute interval showing average, lowest and highest CSI values within the interval. EMG% is displayed as a bar in the right panel.

CSI trend curve with event markers and BS curve. EMG% is displayed as a bar in the right panel. Operation time and numeric value of the actual CSI and BS%.

Displays 3 seconds of EEG waveform. Use Event key to scale up and down.

Main information window with CSI, BS%, EMG%, SQI%, clock, operation time and battery operation.

Sensor impedance, CSI, BS%, clock and operation time. When display E is active, the sensor impedance is updated every 60 seconds. Press Display key firmly down for immediate impedance update.

The CSM always starts with display A

## Battery installation and charging

- Insert the battery CSMX04 correctly into the compartment
- Connect the CSM-Power to the Charge connector on CSM
- Connect mains to CSM-Power
- Check Charge indicator = green
- Fully charged battery in about 4 hours



Battery about 50-percent charged Battery charging when icon animates Battery fully charged (if not animated)

ONLY CSM Battery (CSMX04) will be charged in CSM Monitor Optional 9V Alkaline operational

